


Fuel Probe Assembly Instructions



1. Slide the spacer supports onto the stainless steel plates as shown on the drawing. Place a spacer support about every three inches with the last support about one half of an inch from the end of the plates.
Wear gloves when installing the spacer supports because the stainless steel plates could be sharp. It is best to place the spacer supports on a hard surface and push the stainless steel plates into the spacer slots.
2. Measure the depth of your fuel tank.
3. Secure the stainless steel plates into a vise close to the area to be cut. Use a hack saw to cut the plates $\frac{3}{4}$ of an inch (19 mm) shorter than the measured depth of your fuel tank.
4. Slide the last spacer supports down to about one half of an inch (12.5 mm) from the end of the plates.
5. Secure the stainless steel plates to the head unit using the screws and insulating cup as shown in the drawing. Apply a drop of blue Loctite to the threads of each screw before tightening.